



PARTS CATALOGUE

ECHO WEED & GRASS TRIMMER GT-1000



898 697-2913 0




KIORITZ CORPORATION

TOKYO, JAPAN


Printed in Japan

'860400AD0KW




Key No.	Part No.	Q'ty	Description	KeyNo.	Part No.	Q'ty	Description
1- 5	900 242-0501 0	1	Screw 5 x15	1-21	100 242-0492 0	1	Gasket, crankcase
6	101 514-0492 0	1	Cylinder cover	22	900 810-3620 0	2	Ball bearing
7	101 034-0922 0	1	Cylinder	23	100 100-2913 0	1	Crankshaft ass'y
8	900 242-0602 0	2	Screw 6 x20	24	100 142-0033 0	1	Key (M)
9	101 010-0492 0	1	Gasket. cyl.	25	900 242-0503 0	4	Screw 5 x30
10	101 586-2913 0	1	Spacer	26	100 011-0216 0	1	Piston ring
12	890 115-2913 0	1	Decal	27	100 010-0216 0	1	Piston
13	101 511-2913 0	1	Fan cover	28	100 013-2193 0	1	Piston pin
14	900 600-0000 5	1	Washer 5	29	100 015-0463 0	2	Circlip, piston pin
15	900 605-0000 5	1	Spring washer 5				
16	900 151-0502 0	1	Bolt 5 x20				
17	900 242-0402 0	1	Screw 4 x20				
18	100 213-0593 0	2	Oilseal				
19	100 200-2913 0	1	Crankcase set				
10	-100 215-0393 0	2	Knock pin				


Remark 19 Includes 20




Key No.	Part No.	Q'ty	Pesription	Key No.	Part No.	Q'ty	Description
2- 5	159 026-0393 0	1	Spark plug (CJ-8)	2-35	-177 214-0463 0	1	Washer
6	159 011-0343 2	1	Coil spring	36	-177 215-0492 0	1	Recoil drum
7	159 012-0343 3	1	Cap, spark plug	37	-177 226-0653 0	1	Starter rope
9	156 114-0231 0	1	Grommet	38	-177 227-0533 0	1	Rope guide
10	150 601-2663 0	1	Module	39	-177 228-0653 0	1	Starter grip
11	900 242-0402 0	5	Screw 4 x 20	40	-177 220-0653 0	1	Rewind spring
				41	-177 209-0742 0	1	Starter case
				42	890 112-2673 0	1	Decal, ECHO
21	150 800-2663 0	1	Flywheel	45	163 400-0652 0	1	Switch
22	100 132-0653 0	1	Washer	46	163 810-0652 0	1	Bracket
25	900 242-0401 4	2	Screw 4 x 14	47	610 012-2913 0	1	Shaft, drive
26	150 626-2663 0	1	Ignition coil	48	900 603-0000 8	1	Washer
27	159 113-2363 0	1	Clip				
31	177 305-0492 0	1	Ratchet ass'y				
32	900 502-0000 8	1	Nut 8				
33	100 615-0492 0	1	Gasket, starter				
	177 200-0742 0	1	Starter ass'y consist of 36-41				
34	--900 241-0401 0	1	Screw 4 x 10				



Key No.	Part No.	Q'ty	Description	Key No.	Part No.	Q'ty	Description
3- 5	145 621-0632 0	1	Cover, muffler	3-19	130 301-0492 0	1	Case, air cleaner includes 20
6	900 242-0401 0	4	Screw 4 x 10	20	-178 810-0492 0	1	Bushing
7	145 809-2193 0	1	Lid, muffler	21	178 516-0083 0	1	Spacer
8	145 862-0632 1	1	Screen	22	178 515-0492 0	1	Shutter, choke
9	900 242-0504 0	2	Screw 5 x 40	23	900 242-0505 7	2	Screw 5 x 57
10	145 806-0632 0	1	Muffler				
11	145 510-2193 0	1	Gasket, muffler	24	130 310-0492 2	1	Filter, air
15	130 010-2163 0	1	Gasket, carburetor				
16	130 017-0492 1	1	Insulator				
17	130 016-0492 1	1	Gasket, carburetor				
18	123 000-2913 0	1	Carburetor (WA)				



Key No.	Part No.	Q'ty	Description	Key No.	Part No.	Q'ty	Description
4- 4	305 110-2683 0	1	Stand	4-17	132 007-0753 0	1	Pipe w/grommet
5	100 616-0632 0	1	Cover	18	-132 115-0492 0	1	Grommet
6	900 245-0401 4	2	Tapping screw 4 x 14	19	131 205-0732 0	1	Strainer, fuel
7	900 242-0401 4	4	Screw 4 x 14	20	131 004-0632 0	1	Cap ass'y, fuel tank
8	131 910-2913 0	1	Bracket, fuel tank	21	-131 315-0502 0	1	Filter, check valve
9	131 920-2913 0	1	Cushion	22	-131 314-0632 0	1	Check valve
14	131 010-2913 0	1	Tank, fuel	23	-131 016-0492 0	1	Gasket, fuel tank cap
15	131 924-2913 0	1	Cushion				
16	131 918-2913 0	1	Bracket, fuel tank				




Key No.	Part Number	Q'ty	Description	Key No.	Part Number	Q'ty	Description
5- 1	900 502-0000 6	2	Nut 6	5- 2	-900 600-0000 6	1	Washer 6
2	900 600-0000 6	2	Washer 6	14	-900 500-0000 5	2	Nut 5
3	178 001-0963 0	1	Throttle cable	25	-900 525-0000 6	1	Wing nut 6
7	610 013-0963 0	1	Shaft, drive	28	-900 100-0605 0	1	Bolt 6x50
8	610 217-0963 0	1	Bush	29	-699 010-0963 0	1	Shield
9	610 210-0963 0	1	Housing, drive shaft	30	-900 240-0501 4	2	Screw 5x14
10	890 152-0493 0	1	Decal, guide	31	-699 016-0632 0	1	Cutter
11	351 111-0963 0	1	Grip	32	-699 212-0963 0	1	Guard
12	178 048-0563 0	1	Spacer	33	-900 605-0000 5	2	Spring washer 5
14	900 500-0000 5	1	Nut 5	**	610 400-0963 0	1	Housing ass'y, bearing
15	433 020-0083 0	1	Lock nut 5	35	-900 242-0401 0	1	Screw 4x10
16	178 024-2913 0	1	Bracket, throttle	36	-900 152-0502 5	1	Bolt 5x25
18	900 240-0502 8	1	Screw 5x28	37	-610 410-0963 0	1	Housing, bearing
19	178 110-0533 0	1	Screw	38	-900 513-0001 2	1	Nut 12 L-h
20	178 010-0563 0	1	Throttle trigger	39	-900 802-0600 1	2	Ball bearing 6001
21	178 043-0693 0	1	Spring	40	-610 315-0653 0	1	Spacer
24*	351 600-0963 0	1	Handle	41	-900 702-0002 8	1	Circlip 28
2	-900 600-0000 6	1	Washer 6	42	-610 310-0963 0	1	Shaft, P.T.O.
25	-900 525-0000 6	1	Wing nut 6	43	-900 305-3000 6	1	Pin 3x6
26	-900 100-0604 0	1	Bolt 6x40	44	-610 313-0963 0	1	Plate, adapter, U
27	890 160-2663 1	1	Decal, caution	50	895 112-0033 0	1	Spanner
*	699 000-0963 0	1	Shield ass'y	45	Nonavailable	1	Cap, P.T.O. shaft
				6	Nonavailable	1	Cap, housing

Remarks;

24* : Includes 2, 25 and 26.

* : Consists of 2, 14, 25 and 28 thru 33.

** : Consists of 35 thru 45.



Key No.	Part Number	Q'ty	Description	Key No.	Part Number	Q'ty	Description
6- *	123 000-2913 0	1	Carburetor WA 168	6-20	-123 127-1063 0	1	Retaining, spring
1	-123 130-0296 0	5	Screw	21	-123 172-0432 0	1	Swivel
2	-123 142-0393 0	1	Cover, m. diaphragm	22	-123 127-0393 0	1	Clip, throttle shaft
3	-123 141-0393 0	1	Diaphragm, metering	23	-123 116-0653 0	1	Valve, throttle
4	-123 140-0653 0	1	Gasket, m. diaphragm	24	-123 114-0393 0	1	Screw, thrt. valve
5	-123 145-1633 0	1	Plug, welch	25	-123 126-1063 1	1	Screen, inlet
6	-123 169-1063 0	1	Ring, retaining	26	-123 112-1503 0	1	Pump diaphragm
7	-123 168-1063 1	1	Screen	27	-123 125-0922 0	1	Gasket, fuel pump
8	-123 146-1063 0	1	Plug, welch	28	-123 124-2913 0	1	Cover, fuel pump
9	-123 123-0393 0	1	Lever, metering	29	-123 110-0393 0	1	Screw, pump cover
10	-123 138-0393 0	1	Pin, metering lever	30	-123 133-0632 0	1	Spring, idle adjust
11	-123 139-0393 0	1	Screw, m. lever pin	31	-123 134-0632 0	1	Screw, idle adjst.
12	-123 122-1113 0	1	Spring, meter. lever	32	-Unavailable	1	Body ass'y
13	-123 137-0393 0	1	Valve, inlet needle				
14	-123 119-0393 0	1	Spring, h. s. needle				
15	-123 120-0076 0	1	Needle, high speed				
16	-123 121-0393 0	1	Spring, needle				
17	-123 118-2443 0	1	Needle, idle				
18	-123 113-0393 0	1	Spring, thrt. return				
19	-123 117-0922 0	1	Shaft, throttle				

Remarks : * Consists of 1 thru 32